

# 負荷リスト表

豊田市民文化会館 大ホール

負荷名称	DMX No.	
UH	1	345
	2	346
	3	347
	4	348
	5	349
	6	350
	7	351
	8	352
	9	353
	10	354
	11	355
	12	356
	13	357
	14	358
	15	359
	16	360
	17	361
	18	362
	19	363
	20	364
	21	365
	22	366
	23	367
	24	368
LH	1	315
	2	316
	3	317
	4	318
	5	319
	6	320
	7	321
	8	322
	9	323
	10	324
	11	325
	12	326
	13	327
	14	328
	15	329
	16	330
1B上下	1	81
	2	82
	3	83
	4	84
1B中	1	85
	2	86
	3	87
	4	88
2B上下	1	89
	2	90
	3	91
	4	92
2B中	1	93
	2	94
	3	95
	4	96
3B上下	1	97
	2	98
	3	99
	4	100

負荷名称	DMX No.	
3B中	1	101
	2	102
	3	103
	4	104
4B上下	1	105
	2	106
	3	107
	4	108
4B中	1	109
	2	110
	3	111
	4	112
PS	1	135
	2	136
	3	137
	4	138
	5	139
	6	140
	7	141
	8	142
	9	143
	10	144
	11	145
	12	146
1S	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
	10	10
	11	11
	12	12
	13	13
	14	14
	15	15
	16	16
2S	1	17
	2	18
	3	19
	4	20
	5	21
	6	22
	7	23
	8	24
	9	25
	10	26
	11	27
	12	28
	13	29
	14	30
	15	31
	16	32
3S	1	33
	2	34
	3	35
	4	36

負荷名称	DMX No.		
3S	5	37	
	6	38	
	7	39	
	8	40	
	9	41	
	10	42	
	11	43	
	12	44	
	13	45	
	14	46	
	15	47	
	16	48	
	4S	1	49
		2	50
		3	51
		4	52
5		53	
6		54	
7		55	
8		56	
9		57	
10		58	
11		59	
12		60	
13		61	
14		62	
15		63	
16		64	
5S	1	65	
	2	66	
	3	67	
	4	68	
	5	69	
	6	70	
	7	71	
	8	72	
	9	73	
	10	74	
	11	75	
	12	76	
	13	77	
	14	78	
	15	79	
	16	80	
3FR上	1	155	
	2	156	
	3	157	
	4	158	
	5	159	
	6	160	
	7	161	
	8	162	
4FR上	9	163	
	10	164	
	11	165	
	12	166	
	13	167	
	14	168	
	15	169	
	16	170	

# 負荷リスト表

豊田市民文化会館 大ホール

負荷名称		DMX No.
3FR下	1	171
	2	172
	3	173
	4	174
	5	175
	6	176
	7	177
	8	178
4FR下	9	179
	10	180
	11	181
	12	182
	13	183
	14	184
	15	185
	16	186
1CL	1	187
	2	188
	3	189
	4	190
	5	191
	6	192
	7	193
	8	194
	9	195
	10	196
	11	197
	12	198
	13	199
	14	200
	15	201
	16	202
17	203	
18	204	
19	205	
20	206	
21	207	
22	208	
23	209	
24	210	
2CL	1	211
	2	212
	3	213
	4	214
	5	215
	6	216
	7	217
	8	218
	9	219
	10	220
	11	221
	12	222
上花道	1	147
	2	148
	3	149
	4	150
下花道	1	151
	2	152

負荷名称		DMX No.
下花道	3	153
	4	154
上FC	1	223
	2	224
	3	225
	4	226
	5	227
	6	228
	7	229
	8	230
	9	231
	10	232
	11	233
	12	234
	13	235
	14	236
	15	237
	16	238
	17	239
	18	240
	19	241
	20	242
	21	243
	22	244
	23	245
FC前	1	277
	2	278
	3	279
	4	280
FC迫	1	281
	2	282
	3	283
FC奥	1	287
	2	288
	3	289
	4	290
	5	291
	6	292
	7	293
	8	294
下FC	1	246
	2	247
	3	248
	4	249
	5	250
	6	251
	7	252
	8	253
	9	254
	10	255
	11	256
	12	257
	13	258
	14	259
	15	260
	16	261
	17	262
	18	263

負荷名称		DMX No.
下FC	19	264
	20	265
	21	266
	22	267
	23	268
BD上 舞台奥電源	1	295
	2	296
	3	297
	4	298
	5	299
	6	300
	7	301
	8	302
	9	303
	10	304
BD下 舞台奥電源	1	305
	2	306
	3	307
	4	308
	5	309
	6	310
	7	311
	8	312
	9	313
	10	314
F	1	269
	2	270
	3	271
	4	272
上HF 花道フット	1	273
	2	274
下HF 花道フット	1	275
	2	276
上TOW	1	121
	2	122
	3	123
	4	124
下TOW	1	125
	2	126
	3	127
	4	128
上TOR	1	129
	2	130
	3	131
下TOR	1	132
	2	133
	3	134
OP	1	284
	2	285
	3	286
AL 反響板天板	1	113
	2	114
	3	115
	4	116
	5	117
	6	118
	7	119
	8	120

## 負荷リスト表

豊田市民文化会館 大ホール

負荷名称	DMX No.	
客	1	369
	2	370
	3	371
	4	372
	5	373
	6	374
	7	375
	8	376
	9	377
	10	378
	11	379
	12	380
	13	381
	14	382
	15	383
	16	384
	17	385
	18	386
	19	387
	20	388
	21	389
	22	390
	23	391
	24	392
	25	393
	26	394
	27	395
	28	396
	29	397
	30	398
	31	399
	32	400
	33	401

負荷名称	DMX No.	
客	34	402
	35	403
	36	404
	37	405
	38	406
	39	407
	40	408
	41	409
	42	410
	43	411
	44	412
	予備	45
46		414
47		415
48		416
49		417
50		418
51		419
52		420
53		421
54		422
55		423